

## SERVOTOUGH LaserExact 2950

# ULTRA-LOW TRACE GAS MONITORING OF MULTIPASS LONG PATH LENGTH CELLS IN A COMPACT ANALYZER WITH SMALL INSTALLATION FOOTPRINT



### SERVOTOUGH LaserExact 2950 📣

Specifically designed for extractive trace analysis applications, the LaserExact gas analyzer delivers the exceptional benefits of Tunable Diode Laser (TDL) Technology within a robust and compact analyzer design.

Able to detect gases including  $O_2$ , HCl, HF, NH<sub>3</sub>, CO, CO<sub>2</sub>, H<sub>2</sub>O, H<sub>2</sub>S, the LaserExact combines an advanced multipass long path length cell with Servomex's superior signal processing. Combined with feature rich operation and a range of digital communication options, the result is unsurpassed low ppb detection limits for most gases - making the LaserExact ideal for the measurement of trace gases offline.

**FLEXIBLE** Ultra-low detection of 8 gases: Various communications O<sub>2</sub>, H<sub>2</sub>O, H<sub>2</sub>S, CO, CO<sub>2</sub>, NH<sub>3</sub>, HCI platforms: RS-232, Optical 10 or and HF 10/100 Base T Ethernet, optional fiber optic (ASCII) **EASY TO USE** Intuitive, engineer-friendly Compact design with small interaction and use installation footprint Easily operable via analog and SIL 1 approved digital communication options LOW COST OF OWNERSHIP Drift-free TDL technology High grade laser technology extends maintenance periods, provides long life, zero drift solution reducing costs Remote device interaction via full suite of communications protocols UNRIVALLED PERFORMANCE Manufactured by Servomex - over Uses industry-leading TDL technologies and advanced 60 years' experience innovating algorithms for sensitive monitoring and pioneering gas analysis and thousands of units used in the Ultra-low offline trace gas analysis field every year down to 10ppb (gas specific and application dependent)

### **BENCHMARK COMPLIANCE**

- Designed for Zone 2/Division 2 use
- Designed for use in Zone 2/ Division 2 hazard rated locations
- Designed for Zone 2/Division 2 use without purge

Learn more about the SERVOTOUGH LaserExact 2950 VISIT SERVOMEX.COM





## PRODUCT OVERVIEW: LaserExact 2950

### UNBEATABLE PERFORMANCE FOR OFFLINE LONG PATH CELL MEASUREMENTS

When you work in refinery monitoring processes, industrial gas manufacture or other applications where you need an in situ measurement across long pathways, your preferred device must be able to deliver ultra-sensitive analysis of diverse gases. The flexibility to perform both single and dual monitoring is advantageous and the ideal device will also be easy to integrate into existing process monitoring systems. And we don't believe you should have to compromise.

### A NO COMPROMISE SOLUTION

The LaserExact's advanced TDL technology delivers a fast response time, highly stable performance and minimal interference from background gases. The LaserExact utilises advanced peak-locking technology, which eliminates drift over extended operational periods by automatically tracking on the measured gas absorption line or - in applications where the measured gas is not normally present - tracking the absorption line of another gas present in the stream. This robust tracking mechanism ensures a highly accurate operation by the LaserExact over long periods, with calibration frequencies extended beyond twelve months for many applications.

## UNBEATABLE VALUE OVER PRODUCT LIFE

Designed for easy installation and integration, the LaserExact is immediately ready for operation following the connection of power, sample gas and optional purge gas. With gas concentrations provided as 4-20mA outputs with the option of Ethernet communication, the LaserExact delivers immediate class-leading performance that meets ATEX and Class1 Div2 CSA approvals. With no moving parts or consumables, the LaserExact minimizes operating costs, while the stable, drift-free performance reduces the downtime incurred by the calibration requirements of other analyzer technologies.

## **KEY APPLICATIONS**

- Refinery monitoring: H<sub>2</sub>S and CO<sub>2</sub> (during Natural Gas refinement)
- O<sub>2</sub> monitoring in flare gas recovery system
- HF and HCI impurity monitoring in process gas

## for diverse process and emissions monitoring over longer paths, we recommend LaserSP

If you require a flexible in-situ TDL solution

**ALTERNATIVE PRODUCTS** 

The SERVOTOUGH product range features

for specific application needs.

LaserSP

2930

 $\mathcal{M}$ 

alternative TDL laser products, each optimized

over longer paths, we recommend LaserSP. With 21 gas/gas blend monitoring capabilities, this device is ideal for diverse emissions and process monitoring in hazard rated locations.

# LaserCompact 2940

When you need an in-situ, short distance TDL analyzer, we recommend LaserCompact. This device is optimized for petrochemical, chemical and metallurgy applications.

- Monitoring pure gas impurities in industrial gas production
- Monitoring H<sub>2</sub>S during biogas production
- H<sub>2</sub>O and H<sub>2</sub>S in natural gas





Calorimetry





## PRODUCT DATA: LaserExact 2950

GAS MEASURED	DETECTION LIMIT	MIN. MEASURING RANGE
NH <sub>3</sub>	20ppb	0 - 2ppm
НСІ	5ppb	0 - 0.5ppm
HF	2ppb	0 - 0.2ppb
H <sub>2</sub> S	0.3ppm	0 - 30ppm
0 <sub>2</sub>	3ppm	0 - 300ppm
H <sub>2</sub> 0 (ppm)	10ppb	0 - 1ppm
CO (ppm)	50ppb	0 - 5ppm
CO <sub>2</sub> (ppm)	50ppb	0 - 5ppm

OPTIONS	DESCRIPTION	SPECIFICATION
Analog output	3 x configurable 4-20mA as standard	4-20mA current loop
Relays	3 x relay options: high gas, warning relay, fault relay	Normally closed circuit relays. Output: 1 A at 30v DC/AC
Digital outputs	Diverse options for added flexibility	RS-232, 10 or 10/100 Base, Ethernet and optional fibre optic (ASCII)
Analog input	For process temperature and pressure measurements	4-20mA format
ACCESSORIES	ACCESSORIES AVAILABLE FOR SPECIFIC APPLICATIONS	

CONTACT YOUR LOCAL SERVOMEX BUSINESS CENTER

SAMPLE FOR MEASUREMENTS		
Sample gas	Sample must be dry and oil-free pressurized air or gas, $N_2$ for $O_2$ and $H_2O$ applications	
Flow Control	Recommended 5-10l/min.	
Sample inlet connection	6mm or 1/4" Swagelok (other dimensions on request)	
Sample wetted material	Standard: 304SS, 316SS, borosilicate glass, platinum, platinum/iridium alloy, electroless nickel, Viton®.	
Inlet pressure	0.2-2 bar abs (2.9-29psia)	







## PRODUCT DATA: LaserExact 2950

8

#### DEVICE SPECIFICATION

#### Size:

Unit: 571mm (22.4) Width x
2200mm (7.8") High x 600mm (23.6") Deep

#### Weight:

28kg (62 lbs)

#### **Certifications:**

- ATEX Zone II 3 G Ex nA Nc op is Gc IIC T4, II 3 D Ex td A22 IP65 T100°C
- North America CSA: Class 1, Div. 2, Groups A, B, C and D, Temp. Code T4; non-incendive

IP 65







These analyzers are not intended for any form of use on humans and are not medical devices as described in the Medical Devices Directive 93/42EEC.

AMERICAS BUSINESS CENTER Tel: +1 281 295 5800 Email: americas\_sales@servomex.coi

ASIA PACIFIC BUSINESS CENTRE Tel: +86 (0)21 6489 7570 Email: asia\_sales@servomex.com **Please note:** This document was updated in August 2014. While every effort has been made to ensure accuracy, no responsibility can be accepted for errors or omissions. Data may change, as well as legislation, and you are strongly advised to obtain copies of the most recently issued regulations, standards and guidelines. This document is not intended to form the basis of a contract.

EUROPEAN BUSINESS CENTRE Tel: +31 (0) 79 330 1580 Toll Free: 00800 7378 6639 (NL, D, GB, F) Email: europe sales@servomex.com

LATIN AMERICA BUSINESS CENTER Tel: +55 11 5188 8166 INDIA BUSINESS CENTRE Tel: +91 22 3934 2700 Email: MEI\_sales@servomex.cor

MIDDLE EAST BUSINESS CENTRE Tel: +971 6552 8073 Email: MEI\_sales@servomex.com

SERVOMEX S

### SERVOMEX.COM

Servomex has a policy of constant product improvement and reserves the right to change specifications without notice. © Servomex Group Limited. 2014. A Spectris company. All rights reserved.