

Dust Filter Leak Monitor

PROCESS & EMISSIONS MONITORING SYSTEMS



SPECIFIC FEATURES:

- Designed to differentiate between gross filter failure and dust leakage from faulty/ failing filter systems, including bag filters
- Selection of advanced features and options for improved functionality
- Supports simple and flexible configuration via keypad/display or using the remote PC software tool
- Improved performance over previous models



TECHNOLOGY

SYSTEM DESCRIPTION

The PCME Leak Alert 73 is particularly well suited for use on fabric-filter type dust collectors (baghouses) and provides reliable and robust monitoring of particulate leaks from bags. With its compact, cost-effective transmitter design, pragmatic and reliable monitoring can now be provided for all types of industrial bag filters.

The instrument benefits, first from ENVEA's unique *ElectroDynamic™* Probe Electrification technology, second, from advanced features, enabling the Leak Alert 73 to be configured for all types of bag filters irrespective of cleaning sequence and, finally, a choice of field-upgradeable options to provide quality assurance (QA) features for the user.

The Leak Alert 73 is part of the Leak Alert family of products, which have been designed specifically to detect low and medium levels of dust leakage, in addition to gross bag failure, enabling bag filter users to maximise filter performance.



Dantherm Filtration Ltd. reproo

PRINCIPLE OF OPERATION



Figure 1: Principle of Operation - ElectroDynamic™ sensors

The Leak Alert 73 combines advanced signal processing techniques with ENVEA's unique *ElectroDynamic™* Probe Electrification technology.

When the sensing probe is installed after the bag filter, particles in the airstream interact with the sensing rod to induce a charge signature. The resulting signal is filtered electronically to reject signals outside a defined frequency range (including the DC Triboelectric signal), which makes the instrument less susceptible to changes in particle velocity and virtually eliminates the effect of any particle contamination on the rod.

In bag-filter applications the instrument provides a robust signal proportional to dust emissions, which is used to monitor and detect bag leaks. The instrument has the necessary features to discriminate between the variation in dust due to the bag-cleaning sequence and real leak conditions.

ADVANCED FEATURES

The Leak Alert 73 sensors provide powerful bag-leak detection capability based on the following standard features:

Bag-leak monitoring performance

- High-quality leak response with sufficient dynamic range and time response to track emissions from single and multi-compartment, pulse-cleaned bag filters.
- Instrument drift and minimum detection level below 0.1mg/m with leak monitoring to 500 mg/m.
- Fully configurable warning alarm and limit alarm levels with independent alarm delay.
- Convenient bag-leak output range scaled 0-100%. Option for scaling in defined units (user selectable).
- Bag-leak locating capability by use of the optional Bag Pulse Display Module (see page 3).

Designed for practical bag-filter issues

- Suitable for ATEX/IECEx Dust zones 22 and 20
- Inbuilt surge protection to counter the effects of indirect lightning.
- Industrially hardened enclosure and sensor mechanics provide convenient connections to plant allowing armoured cable use.
- Powered directly from a mains power supply 100–240V AC (24V DC option)
- · Input available for marker pulse from bag-cleaning cycle

Powerful User Interface

- Four-digit display and keypad within instrument (see Figure 3)
- Instrument setup via internal keypad or PC/laptop (requires the optional PC software suite)
- Intuitive multi-level user interface (user setup and seperate engineering setup) with password protection
- Three tri-colour LEDs for Power, emission alarms and instrument self-checks.




Figure 2: PCME LEAK ALERT 73 monitoring bag-leak conditions



Figure 3: LEAK ALERT 73 with lid open showing three LEDs, display and internal setup keys

PRODUCT FEATURES

USER-SELECTABLE ADDED-VALUE OPTIONS

The LEAK ALERT 73 provides a full choice of user-selectable, added-value features. These include the following options:



Figure 4: LEAK ALERT sensor contamination check

SENSOR SPECIFICATIONS

• Automatic insulator Short-Circuit Check for contamination detection

ElectroDynamic™ sensors are tolerant to dust contamination of the sensor rod (unlike Triboelectric systems) due to the non-contact measurement principle; however, build-up of conductive material across the insulator at the base of the rod can lead to error (as with all Probe Electrification systems). For standard, dry dust collector applications contamination is unlikely, but a possibility. The automatically initiated Short-circuit Check provides a reliable method for detecting insulator contamination and hence improved Quality Assurance. For applications where water condensation is likely, ENVEA's patented insulated sensor is a preferred option.

• Electronic Zero and Reference Drift detection

Electronic dust signals are injected into the front end of the sensor electronics to ensure any electronic and signal measurement malfunction is detected. This Quality Assurance feature checks that the sensor electronics are operating within manufacturer specification.

• User Scaling of display

Of assistance to plant personnel wishing to manually scale the display to an approximate known dust level rather than a relative % level.

Feature	Specification							
Ambient Temperature Range	-20°C to +50°C (-4°F to 122°F)							
Sensor Variants	Standard sensor: 0-250°C (482°F) Insulated sensor: 0-250°C (482°F) High-temperature sensor: 0-400°C (752°F),							
Sensor-to-Stack Connection	1½" BSP							
Enclosure Protection Rating	IP65 (with hinged lid closed)							
Power Requirements	100-240V AC, 50/60Hz (32 mA) or 24V DC (300 mA)							
Outputs (standard)	 4-20 mA (500 Ω, isolated) Warning alarm relay (SPST, 1A@24V DC), Fail safe Emission alarm relay (SPST, 1A@24V DC), Fail safe 							
Outputs (optional)	RS-232 (Modbus RTU) RS-485 (Modbus RTU) Tools PC Software suite							
Inputs	Plant Stop signal (output set to zero when plant is off), marker pulse for start of bag-cleaning sequence, multiple calibrations							
External Indicators (3x LEDs)	 Power/sensor OK Warning and limit alarm Self-check status (optional) 							
User Controls	4-digit Display and Setup buttons Options: external display and / or external keypad (excl. Ex sensor version, see Sensor Options on page 4)							
Cable Entries	3x M20 cable glands							

BAG PULSE DISPLAY MODULE

Air Purge

The LEAK ALERT 73 may be upgraded to provide Leak-Locate capability by connecting it to a separate Bag Pulse Display (BPD). This enables plant operators to locate the position of failing bag rows in the dust collector, hence reducing bag-replacement costs and minimising time diagnosing dust collector faults.

Air purge fittings: $\frac{1}{4}$ " BSP connection to instrument airline Options: $\frac{1}{2}$ " BSP or 2" ANSI flanged air purge process connection.




Figure 5: Pulse Display - permits failing bag rows to be identified during bag cleaning (see BPD displays, right)




Requires external supply of 5-10 litres/min of dry, clean (oil-free) instrument air, depending on dust loading.

DIMENSIONS


LEAK ALERT 73

(standard version, shown without external display and optional external keypad)








Sensor Features and Accessories (A-I P)




250°C Stainless Steel







400°C Stainless Steel (with heat shield)



ORDER CODES

LEAK ALERT 73

12345-ABCDEFGHIJ-P

Mechanical Options (1–5)										
1	Stack Temperature	up to 250°C up to 400°C*	standard option	250C 400C						
2	Rod Length	0100*-0500 mm (standard) 0600, 0800, 1000 mm (option)	specify	RODxxxx						
3	Rod Material	Stainless steel Insulated (PTFE)	standard option	S I						
4	Air Purge	not required Air Purge Fitting (1½" BSP) 2" ANSI Flanged Air Purge *	option	0 AP S250						
5	Air Filter/Regulator	not required Filter+Regulator assembly	- option	0 REG						

PC Software Options (PC-ME DUST TOOLS)									
Configuration Options	Device Set								
Real-time Data Options	Online (for viewing emissions) Predict (for baghouse performance monioring)								

*not available with insulated rod option ** excl. 400°C sensor version *choose F or G (these options are exclusive; note that option P requires option F)

Ser	isor Features and A	accessories (A-J, P)				
Α	Sensor Self-checks	- option	0 SC			
В	Electronic Self- Checks	None Manual (zero, reference)	standard option	0 MAN		
С	Scaling Method	Trending 0–100% Scaling Factor	standard option	% SF		
D	Hazardous Zone Classification*	not required ATEX Dust zone 22 ATEX Dust zone 20/21 **				
Е	Power Supply Voltage	100-240V AC (non-Ex only) 24V DC (no cost option)	standard option	AC 24DC		
F	RS-485 Output***	not included RS-485 included***	- option	0 485		
G	RS-232 Data Output ***	- option	0 232			
Н	External Connector for RS-232	standard option	O FLY			
I	Keypad	Internal keypad External keypad	standard option	IK EK		
J	Display	Externally viewable	standard	ED		
Р	Leak-Locate Capability	not included Bag Pulse Display (reg. option F)	- option	O BPD		

For further details on options and order information please contact your local

ENVEA representati	ve							
	1	2	3	4	5	Α	В	С

		2															
Example: SEN73 –	250C	ROD0500	S	AP	REG _	SC	MAN	SF	0	AC	485	0	0	EK	ED] - [BPD

ABOUT ENVEA

As a progressive environmental Company, ENVEA specialises in particulate measurement for industrial processes. With a worldwide reputation for reliability, innovation and technological excellence, the Company produces under the trademark envea™ equipment for concentration and mass monitoring for regulatory, environmental and process control requirements. A dedicated team of qualified application and sales engineers is always on hand and should be consulted in the selection and usage of the most suitable equipment for any particulate application.



ENVEA UK ENVEA House Rose and Crown Road Swavesey / Cambridge - UK CB24 4RB ***** +44 (0)1480 468200



