

# APPLIED ANALYTICS

## OMA-300-CL2 Chlorine Analyzer



### Optimized to monitor:

- ethylene dichloride (EDC) purity in the production of PVC
- $\text{NCl}_3$  in the production of chlorine
- $\text{TiCl}_4$  and vanadium in the production of titanium oxide
- $\text{VOCl}_3$  in organic synthesis
- and more at [www.a-a-inc.com](http://www.a-a-inc.com)

The OMA-300-CL2 showcases the capacity of full-spectrum diode array technology. This solid state instrument smoothly monitors chlorine and derivative compounds' concentrations from trace (ppm) levels up to saturated (high percent) levels, offering seamless dynamic range across a variety of chlorine-related applications.

With Multi-Component Analysis driven by diode array, a single OMA-300-CL2 monitors up to four chemicals in the process stream simultaneously.

FREQUENT EXTENSIONS:


$\text{ClO}_2$

$\text{NCl}_3$

$\text{TiCl}_4$


$\text{V}^{2+}$

$\text{VOCl}_3$



The nova-II Spectrophotometer

- UV-VIS diode array detection  
1,024 photodiodes
- broad spectral response  
190-800nm range
- maximal light throughput  
high-grade optics, strong Xe source
- exceptional in low UV range  
minimal stray light
- CMOS analog circuitry  
low noise, low power consumption
- streamlined, solid state design  
no mirrors or filters



**Optical path of the light signal.** The entire measurement is instantaneous and involves no moving parts.

### MONITORING **FERRIC CHLORIDE** ( $\text{FeCl}_3$ ) AND **CHLORINE** ( $\text{Cl}_2$ ) IN THE MAKING OF PVC

Ethylene dichloride (EDC) is the first intermediate in the manufacturing of the versatile plastic PVC from raw materials. Heated to 500 °C in a cracking furnace, EDC splits into VCM (the precursor to PVC) and recyclable HCl. The EDC entering the furnace sometimes contains ferric chloride, the catalyst used to chlorinate ethylene in creating EDC; this contamination is far from trivial as trace  $\text{FeCl}_3$  is known to foul the furnace. Furthermore, PVC made from EDC with impurities (i.e. low-level  $\text{FeCl}_3$  and chlorine) does not meet the specifications of high-quality PVC.


### MONITORING **TITANIUM TETRACHLORIDE** ( $\text{TiCl}_4$ ) AND **VANADIUM** IN THE PRODUCTION OF TITANIUM OXIDE ( $\text{TiO}_2$ ) PIGMENT

Known in painting as the “whitest white,”  $\text{TiO}_2$  is a widely used pigment. In the chloride production method, titanium ore is converted to  $\text{TiCl}_4$ , from which metallic chloride impurities are discarded; oxidation of purified  $\text{TiCl}_4$  yields bright, finish-ready  $\text{TiO}_2$ . Two yield-critical points in this process require online analysis: 1) ensuring that the  $\text{TiCl}_4$  is vanadium-free to protect pigment quality, and 2) monitoring effluent from the oxidation vessel for unreacted  $\text{TiCl}_4$  to verify the efficiency of conversion to desired  $\text{TiO}_2$ .


### SOLUTION: THE **OMA-300 CHLORINE COMPOUND ANALYZER**

While traditional photometric analyzers struggle with cross-interference between different chlorine compounds, the OMA-300 has **Multi-Component Analysis** powered by diode array technology. To view an animated explanation of how AAI’s proprietary algorithm isolates the precise absorbance of each chlorine compound from the stream absorbance spectrum, please visit: <http://www.a-a-inc.com/multi-component/>

The ability to monitor a species such as chlorine accurately both at trace ppm levels and at high per cent levels is known as **dynamic range**. This versatility revolves around light signal optimization according to current concentration. Chlorine’s high-absorbance 315-330nm range is useful when monitoring very low concentrations, but when the concentration rises significantly, absorbance is too strong in this range and no light is transmitted; in a high %wt chlorine scenario, the moderate-absorbance 390-410nm range is ideal. The OMA-300 shifts wavelength range seamlessly in step with live chlorine concentration, exploiting the broad spectral response of the nova-II for unrivaled dynamic range.



**Chlorine absorbance spectrum.** Priority measurement ranges for low  $\text{Cl}_2$  concentration (range A) and high  $\text{Cl}_2$  concentration (range B). The nova-II shifts wavelength region **automatically**.




		2
1		3
4	5	6


## SAMPLE CONDITIONING

- 1) 0-50 %  $\text{Cl}_2$  and 0-30%  $\text{NCl}_3$ ; Teflon fittings prevent particle generation.
- 2) 0-10ppm **vanadium** in liquid  $\text{TiCl}_4$  stream; used in the production of white  $\text{TiO}_2$  pigment.
- 3) 0-100ppmv  $\text{Cl}_2$  in vent stream; used downstream of a wet scrubber system for environmental compliance.
- 4) 0-10ppm  **$\text{VCl}_3$**  in liquid  $\text{TiCl}_4$  stream; used to measure  $\text{TiCl}_4$  purity in a distillation operation.
- 5) 0-2,000 ppm  **$\text{NCl}_3$**  in gas; used for safety.
- 6) 0-10ppm  **$\text{VOCl}_3$**  in liquid.

# S P E C I F I C A T I O N S



STANDARD OMA-300 CHLORINE COMPOUND ANALYZER.  
COMMON OPTIONS SHOWN IN RED.



<b>Measurement Technology</b>	UV-VIS diode array spectrometer (nova-II)	
<b>Light Source</b>	Pulsed xenon lamp (~5 year lifespan); deuterium and tungsten sources available	
<b>Sample Introduction</b>	Flow-through cell; standard or custom-design sampling system (optional)	
<b>Accuracy (by Range)</b>	<b>Cl<sub>2</sub></b> 0-100 ppm: ±5 ppm 0-10,000 ppm: ±2% full scale or 5 ppm* 0-100%: ±2% full scale <b>TiCl<sub>4</sub></b> 0-2,000 ppm: ±15 ppm 0-10,000 ppm: ±1% full scale <b>vanadium</b> 0-5 ppm: ±0.3 ppm	<b>FeCl<sub>3</sub></b> 0-300 ppm: ±1% full scale 0-10,000 ppm: ±1% full scale <b>NCl<sub>3</sub></b> 0-100 ppm: ±5 ppm 0-10,000 ppm: ±1% full scale 0-5%: ±1% full scale (*whichever larger)
<b>Calibration</b>	For most applications, factory calibrated with certified calibration gases/liquids	
<b>Verification</b>	Easy verification/validation with gas/liquid samples or neutral density filters	
<b>Ambient Temperature</b>	Standard: 0 to 55 °C (32 to 131 °F);	Optional: -20 to 55 °C (-4 to 131 °F)
<b>Sample Temperature</b>	-20 to 150 °C (-4 to 302 °F)	
<b>Sample Pressure</b>	Immersion probe: 100 bar (1470psig)	Flow cell: 206 bar (3000 psi)
<b>Environment</b>	Indoor/outdoor (no shelter required)	
<b>Size</b>	Analyzer: 24" H x 20" W x 8" D (610mm H x 508mm W x 203mm D) Optional sampling system: 24" H x 30" W x 8" D (610mm H x 760mm W x 200mm D)	
<b>Weight</b>	32 lbs. (15 kg)	
<b>Wetted Materials</b>	Analyzer: Teflon, K7 glass, Kalrez, Hastelloy C-276 Optional sampling system: Teflon, quartz, Kalrez, Hastelloy C-276	
<b>Outputs</b>	One galvanically isolated 4-20mA output per component; modbus TCP/IP (optional); RS232 (optional); Fieldbus, Profibus, and HART (all optional); two digital outputs for fault and sampling system control (user programmable)	
<b>Electrical Requirements</b>	85 to 264 VAC 47 to 63 Hz	
<b>Power Consumption</b>	45 watts	
<b>Area Classification</b>	General Purpose (standard) / Class I, Div. 2 (optional) Class I, Div. 1 (optional) / ATEX Exp II 2(2) GD (optional)	

## HEADQUARTERS

**Applied Analytics, Inc.**  
Concord, MA, USA  
Tel: (978) 287-4222  
Fax: (978) 287-5222  
sales@a-a-inc.com

## NORTH AMERICA

**Applied Analytics North America, Ltd.**  
Houston, TX, USA  
sales@appliedanalytics.us

## EUROPE

**Applied Analytics Europe, SpA**  
Milan, Italy  
sales@appliedanalytics.eu

## MIDDLE EAST

**Applied Analytics Middle East (FZE)**  
Sharjah, United Arab Emirates  
sales@appliedanalytics.ae

## ASIA PACIFIC

**Applied Analytics Asia Pte. Ltd.**  
Singapore  
sales@appliedanalytics.com.sg

## INDIA

**Applied Analytics (India) Pte. Ltd.**  
Mumbai, India  
sales@appliedanalytics.in

© 2011 Applied Analytics Group B.V. Products or references stated may be trademarks or registered trademarks of their respective owners. All rights reserved. Information in this document subject to change without notice. Consult our website for the most updated information.

**MADE IN USA**

**www.a-a-inc.com**

**APPLIED**  
ANALYTICS